


# SATA LM2000 B & K HVLP Anodized Teal Green SATA LM2000 B, H & K RP Conventional Nickel Plated



- Part # Description**
- 109 Air inlet fitting, 1/4" BSP
  - 240 Air piston packing
  - 422 Needle and air piston packing
  - 901 Universal spanner wrench
  - 1503 Fan control screw
  - 1826 Non-drip device, pk of 4
  - 2188 Fan control, gravity
  - 2691 Cup and deck assembly, conventional
  - 2733 Deck only
  - 3426 Circlip
  - 3509 Cleaning brush
  - 3624 Pin, micrometer
  - 3699 Pin, lower trigger
  - 3756 Deep socket
  - 3988 Paint sieve, pk of 20
  - 3988-5 Paint sieve, pk of 5
  - 6007 Standard cleaning brush, pk of 10
  - 6213 Trigger service set
  - 8011 Cap nut, 3/8
  - 8029 Hose connect GR
  - 8052 Retaining ring
  - 10520 Needle spring, pk of 12 #17897
  - 12591 Pin, upper trigger
  - 16162 Swivel fitting, /BSP
  - 17152 Air piston spring, pk of 12 #27813
  - 17525 Lock spring
  - 17897 Needle spring
  - 21832 Needle packing spring
  - 23275 Packing, needle
  - 24000 Tool Set, LM2000
  - 26120 Aluminum cup, 1.0 liter
  - 26567 Mixing nozzle
  - 27094 Air piston packing holder
  - 27771 Air micrometer with gauge
  - 27813 Air piston spring
  - 29629 Air piston, LM2000
  - 35667 Paint pipe, R 3/8
  - 38265 Material filter, R 3/8
  - 45286 Drip proof, pk of 4
  - 49395 0.6 liter cup lid
  - 50195 Sieve, conventional pk of 2
  - 50542 Lock nut, fluid control
  - 51680 Cup gasket, pk of 4
  - 51839 Needle packing spring, pk of 12 #21832
  - 53595 0.6 liter plastic gravity cup
  - 53603 Air micrometer
  - 54080 Packing set, LM2000
  - 54221 Fan control, LM2000 H+K
  - 54957 Repair kit, LM2000
  - 55939 Needle rod, 4 & 5mm
  - 56234 Needle tip, 4 & 5mm
  - 61416 Fluid control service set
  - 62513 Air distribution ring, LM2000
  - 64543 Allen wrench, 2mm
  - 65557 Knob, fan control
  - 69872 "O" Ring, fan control
  - 71431 Allen wrench, 4mm
  - 71555 Plastic lid, pk of 3
  - 76307 Socket wrench
  - 80168 1L Aluminum cup
  - 83758 Fluid control
  - 86850 Needle packing holder
  - 89391 Trigger, with piston pad
  - 91108 Nipple and nut
  - 91140 QC w/Nipple
  - 91157 QC w/Filter and nipple

LM2000/B CONVENTIONAL

Nozzle Size	LM2000
0.8	26690
1.0	26716
1.3	26724
1.6	26732
1.8	26740
2.0	26757
2.5	26765
3.0	26781
4.0	26799
5.0	26807

LM2000 Slit Nozzle Sets

Nozzle Size	LM2000
2.5/55	28860
3.0/55	28936
4.0/79	29090

LM2000/B HVLP

Nozzle Size	LM2000/B HVLP	Test Air Cap
1.4 HVLP	30106	67041
1.7 HVLP	30643	67231
1.9 HVLP	30742	67249
2.1 HVLP	31047	67231

LM2000/K HVLP

Nozzle Size	LM2000/K HVLP	Test Air Cap
0.9 HVLP	26823	25478
1.1 HVLP	26856	25478
1.3 HVLP	26864	25478
1.5 HVLP	26872	25478

LM2000/H CONVENTIONAL

Nozzle Size	LM2000
1.6	26732
1.8	26740
2.0	26757

LM2000/K CONVENTIONAL

Nozzle Size	LM2000
1.0	26716
1.3	26724
1.6	26732
2.0	26757
2.5	26765
3.0	26781
4.0	26799

□ Indicates parts contained in LM2000 repair kit, part number 54957

\* Indicates LM2000 packing set, part number 54080

\*\* Indicates parts available separately or in a service set

\*\*\* Indicates package of 12 springs part number 10520 (spring #17897) part number 17152 (spring #278136) part number 51839 (spring #21832)